







Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0101	11020434		Deckel
0102	12017912		Abdeckung
0103	10004102		Dichtung-Begrenzer
0104	11020430		Abdeckung
0105	00624112		Filter
0106	12017897		Rohr
0107	12017904		Abdeckung
0108	11020438		Abdeckung
0109	12017911		Stutzen
0110	10004094		Dichtung-Begrenzer
0111	00656637		Führung
0112	10004097		Lichtleiter
0113	12017968		Filter
0114	10004103		Drehgriff
0115	10004096		Feder
0116	10004095		Träger
0117	10004098		Abdeckung
8001	00573933		Polsterdüse
8400	18027669		Gebrauchsanleitung
8800	00406463		Staubsauger
8001	00461406		Fugendüse
8002	17001022		Bodendüse
8003	00577343		Hartbodendüse
8004	00573934		Halter
8005	00573933		Polsterdüse
8006	17001023	17004257	Bodendüse
8007	17000330	17003058	Hartbodendüse
8008	17000182		Düse

8009	17000183		Fugendüse
8010	17000181		Polsterdüse
8011	17001378	17004257	Bodendüse
8012	00575625		Turbobürste
8013	00575636		Bürste
8014	00579308		Turbobürste






Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0201	12017903		Deckel
0202	12017902		Gehäuse
0203	12017900		Deckel
0204	12017901		Dämpfer
0205	12006624		Gebläsemotor
0206	12017899		Gehäuse
0207	12017909		Isolierteil
0208	12017583		Motorsteuerungsmodul
0209	10004091		Schlauch
0210	00623600		Ventil
0212	10004090		Draht
0213	10004093		Träger
8001	00573933		Polsterdüse
8400	18027669		Gebrauchsanleitung
8800	00406463		Staubsauger
8001	00461406		Fugendüse
8002	17001022		Bodendüse
8003	00577343		Hartbodendüse
8004	00573934		Halter
8005	00573933		Polsterdüse
8006	17001023	17004257	Bodendüse
8007	17000330	17003058	Hartbodendüse
8008	17000182		Düse
8009	17000183		Fugendüse
8010	17000181		Polsterdüse
8011	17001378	17004257	Bodendüse
8012	00575625		Turbobürste
8013	00575636		Bürste


8014	00579308		Turbobürste
------	--------------------------	--	-------------



Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0301	11020211		Gehäuse-Unterteil
0302	12017581		Griff
0303	12017582		Kabeltrommel
0304	12017896		Dichtung-Begrenzer
0305	11020431		Gehäuseteil
0309	10003191		Rolle
8001	00573933		Polsterdüse
8400	18027669		Gebrauchsanleitung
8800	00406463		Staubsauger
8001	00461406		Fugendüse
8002	17001022		Bodendüse
8003	00577343		Hartbodendüse
8004	00573934		Halter
8005	00573933		Polsterdüse
8006	17001023	17004257	Bodendüse
8007	17000330	17003058	Hartbodendüse
8008	17000182		Düse
8009	17000183		Fugendüse
8010	17000181		Polsterdüse
8011	17001378	17004257	Bodendüse
8012	00575625		Turbobürste
8013	00575636		Bürste
8014	00579308		Turbobürste



Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
8001	00573933		Polsterdüse
8400	18027669		Gebrauchsanleitung
8800	00406463		Staubsauger
0401	12017908		Filter
0402	10004099		Griff
0403	12019922		Filter
0404	10004100		Dichtung-Begrenzer
0405	11025091		Staubbehälter
0406	10004938		Gummifuss
8001	00461406		Fugendüse
8002	17001022		Bodendüse
8003	00577343		Hartbodendüse
8004	00573934		Halter
8005	00573933		Polsterdüse
8006	17001023	17004257	Bodendüse
8007	17000330	17003058	Hartbodendüse
8008	17000182		Düse
8009	17000183		Fugendüse
8010	17000181		Polsterdüse
8011	17001378	17004257	Bodendüse
8012	00575625		Turbobürste
8013	00575636		Bürste
8014	00579308		Turbobürste



Positionsnr	Ersatzteilnummr	Ersatz	Beschreibung
0501	00575268		Rohr
0503	00461406		Fugendüse
0505	00576794		Griff
0506	00577944		Schlauch
0512	00573934		Halter
8001	00573933		Polsterdüse
8400	18027669		Gebrauchsanleitung
8800	00406463		Staubsauger
8001	00461406		Fugendüse
8002	17001022		Bodendüse
8003	00577343		Hartbodendüse
8004	00573934		Halter
8005	00573933		Polsterdüse
8006	17001023	17004257	Bodendüse
8007	17000330	17003058	Hartbodendüse
8008	17000182		Düse
8009	17000183		Fugendüse
8010	17000181		Polsterdüse
8011	17001378	17004257	Bodendüse
8012	00575625		Turbobürste
8013	00575636		Bürste
8014	00579308		Turbobürste
0507	17004257		Bodendüse
0508	00576770		Hartbodendüse