










0199




Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0101	11039378		Ház
0102	00020655		Madártoll
0103	10015006		tartó
0104	10015028		gomb
0105	11040298		Lakásbázis
0106	10000212		Gumi láb
0107	12003509		Csatlakozó kábel



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0201	10015022		Fedél
0202	11039380		Lengőkar
0204	10014994		Motorvezérlő modul
0206	10015023		Fedél
0207	10003815		Fedél
0208	10015031		Forgó fogantyú
0209	10004647		pecsét
0210	00020659		pecsét
0211	00638020		Szénkefe
0205	11039382		Lengőkar
0203	11052445		Motor
0212	12042434		Készlet
0213	10026707		Ventilátorkerék
0215	10028563		Gear/Spur Gear
0216	10028562		kúpkerék



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0301	11039341		Csere keverőtál
0302	12034497		Fedél
0303	00650542		Legyintés
0305	00080060		tésztahorog
0306	00619166		Terelő
0304	00650543		Legyintés



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0401	00659887		Ház
0402	12013001		Ház teteje
0403	00627100		csatolás
0404	00621923	00630760	átvevő
0405	00630767		foglalat
0406	00621922		Vezetés
0407	00080159		Súrlódó tárcsa - tartozékok
0408	00083577		Rasp megfordítható tárcsa durva/finom
0409	00642221		Vágókorong - tartozékok