










0199



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0101	11039304		Ház
0102	00020655		Madártoll
0103	10015006		tartó
0104	10015028		gomb
0105	11039331		Lakásbázis
0106	10000212		Gumi láb
0107	00653136		Csatlakozó kábel



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0201	10015022		Fedél
0202	11039325		Lengőkar
0204	10014994		Motorvezérlő modul
0205	11039329		Lengőkar
0206	10015023		Fedél
0207	10002502		Fedél
0208	10014995		Forgó fogantyú
0209	10004647		pecsét
0210	00020659		pecsét
0211	00638020		Szénkefe
0203	11052445		Motor
0212	12042434		Készlet
0213	10026707		Ventilátorkerék
0215	10028563		Gear/Spur Gear
0216	10028562		kúpkerék



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0301	11046135		Csere keverőtál
0302	12034497		Fedél
0303	00650542		Legyintés
0304	00653926		Legyintés
0305	00080060		tésztahorog
0306	00619166		Terelő