










0199






Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0101	11039376		Ház
0102	00020655		Madártoll
0103	10015006		tartó
0104	10015032		gomb
0105	11040296		Lakásbázis
0106	10000212		Gumi láb
0107	12003509		Csatlakozó kábel




Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0201	10015033		Fedél
0202	11039383		Lengőkar
0204	10015034		Vezérlő modul
0205	11039381		Lengőkar
0206	10015023		Fedél
0207	10003815		Fedél
0208	10015029		Forgó fogantyú
0209	10004647		pecsét
0210	00020659		pecsét
0211	00638020		Szénkefe
0213	00621908		Kapcsoló elem
0203	11052442		Motor
0212	12042424		Készlet
0214	10026707		Ventilátorkerék
0215	10028563		Gear/Spur Gear
0216	10028562		kúpkerék



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0301	11039341		Csere keverőtál
0302	12034497		Fedél
0303	00650542		Legyintés
0304	00650543		Legyintés
0305	00080060		tésztahorog
0306	00619166		Terelő



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0401	00659887		Ház
0402	12013001		Ház teteje
0403	00627100		csatolás
0404	00621923	00630760	átvevő
0405	00630767		foglalat
0406	00621922		Vezetés
0407	00080159		Súrlódó tárcsa - tartozékok
0410	12014970		Keverő tartozék - tartozékok
0411	00754767		súrlódó tárcsa
0412	00627102	10005579	Fedél
0413	00653191		tartály
0414	00659892		kúp
0415	00622178		Kés
0416	00622179		átvevő
0408	00083577		Rasp megfordítható tárcsa durva/finom
0409	00659888		vágótárcsa



Positionsnummer	Ersatzteilnummer	Ersatz	Beschreibung
0501	00262066		Ház
0502	00050366		szállítócsiga
0503	12008456		Stuffer
0504	00620949		Kés
0505	00620950		Perforált tárcsa - tartozékok
0506	00050365		csavaros gyűrű
0507	00020470	00418076	csatolás
0508	00028277		pecsét
0510	00659893		Töltőtál
0511	00627103		állvány
0512	00029643	10002430	Láb